

REAR DIFFUSER W/OUT CLIPS

INSTALLATION MANUAL

Disclaimer

These are fitting guidelines only and we highly recommend installations are undertaken by a professional. Maxton Design Ireland can't be held liable for any damages or liabilities that may arise from following any guidelines given by the Company.

Vehicle modifications caused by the usage, abuse, or incorrect installation of Maxton Design products might result in significant vehicle malfunction. Vehicle damage, major bodily injury, disability, and/or death are among the dangers. Any changes you make to your or someone else's car using Maxton Design goods are your responsibility. Maxton Design Ireland is not responsible for any changes made to automobiles as a result of the usage or abuse of its product and will not be held accountable. If you have little to no expertise installing any of the products sold via maxtondesignireland.ie website, professional installation is highly suggested.

Products are sold as-is, and we are not responsible for any damages or injuries sustained during installation or subsequent use of the vehicle. Because proper installation is crucial to our product's performance and longevity, please go through the documentation carefully and test your installation before resuming driving.



COMPLETE SET CONTAINS:

- Rear Diffuser without Clips
- Mounting Kit
- Mounting Manual



For more Installation Manuals visit www.maxtondesignireland.ie/fitting-manuals

1 DISMOUNT

Dismount the original diffuser. Access to the underside of the car is needed, a lift or a jack are most suitable.



2 NOTE: NO CLIPS

This fitting manual is applicable to diffusers that do not arrive with clips, see photo.



SLIDE INTO PLACE

Slide the Maxton Design Rear Diffuser on. Apply some pressure to the product and ensure it is firmly pushed into place.



SECURE THE TOP

Using self-tapping screws, screw through the rear bumper by the "pocket" areas where the lip of the diffuser (photo 2) is pushed into. This will secure the product to the car.



SECURE THE BOTTOM

For added security, also use self-tapping screws on the bottom of the diffuser. See the circled areas in the photo.



6 ENJOY YOUR NEW MODIFICATION!





Please note these instructions are for guidance only. It is your responsibility to ensure the installation is undertaken in a safe and correct way. We strongly recommend you leave the installation to a qualified professional.

Thank you for choosing Maxton Design!

We hope our product will meet your expectations. Let us know if you have any questions.

> info@maxtondesignirelan.ie www.maxtondesignireland.ie

